

APPLICATION OF STICKERS TO PADDING

Your lettering as shipped has the lettering sandwiched between a cardboard backing and a carrier tape.

Supplies needed:

Cleaning fluid (such as rubbing alcohol, Windex, etc.)

Tape measure, ruler, etc.

Masking tape

Squeegee or other hard, smooth piece of plastic

1. Lay padding down on flat surface.
2. Clean padding.
3. Place lettering on padding at desired location with the cardboard backing down. Use tape measure, etc. to verify that the lettering is square to the padding.
4. Place masking tape along one of the long sides of the lettering to secure in place.
5. Using the masking tape as a hinge, fold the lettering back so the underside is showing.
6. Remove cardboard backing, making sure that the lettering doesn't fold over and touch either itself or the padding.
7. While keeping solid tension on the lettering fold the lettering back over to apply to the padding.
8. Using the squeegee, rub over the top of the lettering to additionally secure the lettering to the padding.
9. Remove the masking tape.
10. Remove the carrier tape.
11. Use squeegee to work out any bubbles if necessary.